

Simpled

KA-SP Wireless Keypad Security is just a touch away User Manual



Preface

Dear customer.

Thank you for purchasing this product. To make better use of it. please read this manual carefully. If you have any doubt regarding to installation or maintenance, please feel free to contact your local agent.

Specifications

Model : KA-SP Dimensions W67.7mm x H96.3mm x T29.9mm Power: 4 AAA Voltage : Standy-by power consumption < 10uA

Accessories

User Manual

Manual



Double-sided

Screw pipe x 2

tape x 1

Screw x 2


Installation

*If the mounting surface is flat and smooth, please use the tape to secure the keypad. In this case, the mounting plate is not needed.

*If the mounting surface is uneven, following installation shall be applied.

1 Draw positioning marks on the 2 Fix the mounting plate with the screws. Use the screw pipes dimensions of the keynad and drill screwholes accordingly.





Glue the keypad on the mounting plate with the double



Battery installation

Remove the screw, squeeze the clamp and pull the battery holder out.





Pair a keypad

Enter paring

- If the keypad is not paired to any lock, press any key to enter paring mode.
- If the keypad has paired to a lock previously. press *529# to enter paring mode.
- Add a keypad to a lock

On the APP, select the lock that supports wireless kevpad, press Settings→Wireless keypad→Add wireless keypad, and then follow the steps prompted to finish the pairing process.

Operations

Key in passcode and end with "#". If the passcode is correct, the green LED lights up for 2 Unlock with seconds, and the keypad gives a long beep. passcode If the passcode is incorrect, the red LED lights up for 2 seconds, and the keypad gives 4 short beeps. 1 2 (Turn on/off th On the APP select the lock that is paired with the wireless sound of the keypad, press Settings → Lock Sound → Turn on/off wireless keypad When the battery is low, the battery alert LED (3) Low battery

Reset the keypad to factory mode

disactivated.

At times of need, the wireless keypad can be reset to factory default mode by applying following steps:



alert



lights up as soon as the wireless keypad is

activated, and it dies out after the keypad is





Light Status

When the batteries are loaded: Correct passcode: Green LED lights up for 2 seconds Incorrect passcode: Red LED lights up for 2 seconds Press any key, Green LED flickers 1 time Unable to connect to a lock: Red LED flickers 3 times Low battery: Low battery alert LED lights up Paring mode: The green light keeps flickering

Limited Warranty

- 1. For any defect in material and workmanship, the original purchaser of the product can:
- 1) Return or ask for a replacement within 7 invoice days.
- 2) Ask for free repair in 365 invoice days.

This warranty does not cover defects caused by modification, alteration,

misuse or physical abuse of the product.

We continuously optimize products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products without prior notice.




Simpled.



Discover our Range of Products:

Simpled is a London-based tech company rolling out innovative IoT devices to elevate the smart home experience. Control your home with a range of smart security devices from Simpled. Whether it's a Smart Door Lock, a Camera Doorbell, Simpled put you in control of your home security.

Want more Accessories? Here is all you want:













Easy Amazon Review Scan me!

Simpled

Contact us



We're just happy that you're happy. If you don't know how to express your newfound joy, we've got a few suggestions...



Tell your friends and family



Share your experience by writing a review on Amazon



Connect with us on simpled.tech Facebook, Twitter and instagram



Our friendly customer service team will work hard to put a smile back on your face.

Here's how we can connect:



